$14 \text{VT_Bypass_Instr.txt}$

Lucas 14VT Bypass:

White 6 pin connector:

Join pin 1 (BW) to pin 3 (B).

Black 16 pin connector:

Cut wire to pin 14 (PB) and cut wire to pin 16 (UK)